


Operating Instructions for the RB Clip Gun



Fire the gun...

Using the built-in guides, align the clip gun over the tubing so that it lays flat against the surface of the wood. Fire the gun two times to insure that each clip is fully seated.



...then rotate off!

While keeping the handle depressed, lift the front of the gun off the clip, using the back of the gun as a rotational axis. Then lift the entire gun off the surface.

Maintenance tip: A periodic spray of silicone into the nose of the gun and clip chute should be all the clip gun needs to remain in good working condition. This will lubricate the driver blade and clean out any debris.

 ***Peter Mangone, Inc.***

PLUMBING INSTALLATION PRODUCTS

800-338-2448